



Operating and Installation Instructions

Micro Diaphragm Gas Sampling Pumps

Type Ranges:	UNMP05S	UNMP09S	UNMP015S
	UNMP05M	UNMP09M	UNMP015M
	UNMP05L	UNMP09L	UNMP015L
	UNMP05B	UNMP09B	UNMP015B

You have selected a high-quality KNF product; the following tips will help you operate it safely and reliably over a long period of time. Carefully study the Operating and Installation Instructions before using the pumps and observe at all times the relevant instructions to avoid dangerous situations. The manual was produced for the serial pumps stated above. With customer-specified projects (pump types starting with "PU" or "MPU") there could be differences in detail. For customer-specified projects please therefore take into account any agreed technical specifications, as well as these instructions.

	List of Contents	Page
	1. Description, Operating Conditions.....	2
	2. Safety.....	2
	3. Installation	4
	4. Operation	5
	5. Trouble Shooting.....	6
	6. Product Return.....	7

KNF Neuberger, Inc
2 Black Forest Rd
Trenton, NJ 08691-1810

Phone: 609-890-8600
Fax: 609-890-8323

www.knf.com/usa.htm

Ident#121551-211459
Revision (05/12)

1. Description, Operating Conditions

KNF pumps in the NMP range transfer, evacuate and compress 100% oil-free. In operation they are maintenance-free

- See the type- plate or data sheet for full electrical data.

1.1. Operating Conditions

Handling air, gases, and vapours at temperatures between + 5 °C...+ 40 °C.

For maximum permissible operating pressure, ultimate vacuum, and flow capacity see data sheet.

Ambient temperature during operation: between + 5 °C...+ 40 °C

The pumps must not be used in areas where there is a danger of explosion.

Before pumping a medium, the compatibility of materials of pump head, diaphragm and valves with the medium must be checked (for pump materials: see data sheet).

KNF pumps in the NMP range must not be used for liquids. You will find suitable liquid pumps in our Product Program.

If your potential application lies outside the above limits discuss it with our technical adviser (see last page for contact telephone number).

2. Safety

i Note the safety precautions in chapters 3. *Installation and connection*, and 4. *Operation*.

The pumps are built according to the generally recognized rules of technology and in accordance with the occupational safety and accident prevention regulations. Nevertheless, dangers can result during their use which lead to injuries to the user or others, or to damage to the pump or other property.

Only use the pumps when they are in a good technical and proper working order, in accordance with their intended use, observing the safety advice within the Operating and Installation Instructions, at all times.

Personnel Make sure that only trained and instructed personnel or specially trained personnel work on the pumps. This especially applies to assembly, connection and servicing work.

Make sure that the personnel has read and understood the Operating and Installation Instructions, and in particular the "Safety" chapter.

Working in a safety-conscious manner Observe the accident prevention and safety regulations when performing any work on the pump and during operation.

Handling dangerous media When transferring dangerous media, observe the safety regulations when handling these media.

Handling combustible media Be aware that the pumps are not designed to be explosion-proof.

Make sure the temperature of the medium is always sufficiently below the ignition temperature of the medium, to avoid ignition or explosion. This also applies for unusual operational situations.

Note that the temperature of the medium increases when the pump compresses the medium.

Hence, make sure the temperature of the medium is sufficiently below the ignition temperature of the medium, even when it is compressed to the maximum permissible operating pressure of the pump.

If necessary, consider any external sources of energy, such as radiation, that may add heat to the medium.

In case of doubt, consult the KNF customer service.

Environmental protection Store all replacement parts in a protected manner and dispose of them properly in accordance with the applicable environmental protection regulations. Observe the respective national and international regulations. This especially applies to parts contaminated with toxic substances.

EC Directives / Standards For the purposes of the Machinery Directive 2006/42/EC, pumps are "partly completed machinery," and are therefore to be regarded as not ready for use. Partly completed machinery may not be commissioned until such time as it has been determined that the machine in which the partly completed machinery is to be assembled is in conformity with the provisions of the Machinery Directive 2006/42/EC. The essential requirements of Annex I of Directive 2006/42/EC (general principles) are applied and observed.



The pumps conform to the EC Directive 2004/108/EC concerning Electromagnetic Compatibility.

The following harmonized standards have been used:

UNMP05M UNMP09M	UNMP05L UNMP09L UNMP015L	UNMP05B UNMP09B	UNMP015M
DIN EN 61000-6-3	DIN EN 55022 (Klasse B)	DIN EN 61000-6-1/2/3/4	DIN EN 55014-1
	DIN EN 61000-4-2/3/4/5/6/8		

Tab. 1

Customer service and repairs Only have repairs to the pumps carried out by the KNF Customer Service responsible.

3. Installation

Pumps in the NMP range are OEM models intended for installation in equipment. When installing them make certain that accident prevention regulations, and safety instructions, including those for subsequent operation are observed.

The dimensions of the mountings are given in Data Sheet.

Fit the pump at the highest point in the system, so that condensate cannot collect in the head of the pump - that prolongs working life.

Compare the supply data with the motor data.

With dc motors the wires must be connected to the correct poles.

For brushless DC motors (type designation ending with B):

- Caution; incorrect lead connection will damage motor electronics.
- Correct connection:
 - + red cable
 - black cable

In the electrical installation, arrangements (complying with EN 60335-1) must be made for disconnecting the pump motor from the electrical supply.

4. Operation

Specific safety instructions for the media being handled must be observed.

Before pumping a medium, the compatibility of materials of pump head, diaphragm and valves with the medium must be checked (for pump materials: see data sheet)

The pump must not start against pressure or vacuum. When it is switched on the pressure in the suction and pressure lines must be atmospheric.

The maximum permissible operating pressure (see data sheet) must not be exceeded.

Exception: If the data sheet includes values for intermittent operation, they may be employed briefly.

To prevent the maximum permissible operating pressure being exceeded, restriction or control of the air or gas flow should only be carried out in the suction line.

If restriction or control of the air or gas flow is made on the pressure side ensure that the maximum permissible operating pressure is not exceeded.

When the pump is at a standstill the inlet and exhaust must be at normal atmospheric pressure.

5. Trouble Shooting

Flow, pressure or vacuum are too low, or: Pump produces no flow:

- Connections or lines are blocked.
- There is a leak at a connector, in a line, or in the pump head.
- An external valve is closed, or a filter blocked.
- Liquid (condensate) has collected in the pump head.
 - ▶ Let the pump run for a few minutes pumping air (if necessary for safety reasons: pumping an inert gas.)
 - ▶ Install the pump at the highest point in the system.
- The cross-section of pneumatic lines, or connected components is too small, or they are restricted.
- There is pressure on the pressure side, and at the same time vacuum, or a pressure above atmospheric, on the suction side:
 - ▶ The pump is not designed for this condition.

6. Product Return

- KNF provides warranty and non-warranty repair services for all products.
- A Return Material Authorization (RMA) number is required for all product returns.
 - To receive an RMA number, submit a completed Decontamination Declaration form to rma@knf.com
- The Decontamination Declaration form can be obtained from our website or by contacting KNF Technical Services.
 - <http://www.knf.com/pdfs/decontamdec.doc>
 - Phone: 609-890-8600
- Product return instructions will be provided when the RMA is issued.

KNF Neuberger, Inc
2 Black Forest Rd
Trenton, NJ 08691-1810

Phone 609-890-8600
Fax 609-890-8323

www.knf.com/usa.htm

